

TAPE RUNNER XL^{TM/MC} Refill - #3915

double-sided adhesive refill
recharge d'adhésif double face
recarga de adhesivo de dos caras



Great for scrapbook paper & photos, card making and other paper crafts.

To Refill:

1. Pinch the two tabs near front and open.
2. Lift out used cartridge and replace with a new refill. (as shown)
3. Snap cover closed.

For Best Results:

- Use slow, consistent movement with pivoting head flat on paper's surface.

Parfait pour le papier et les photos dans les albums de souvenirs, la fabrication de cartes et autres projets.

Pour recharger:

1. Pincer les deux pattes près de l'avant de l'applicateur et ouvrir.
2. Soulever la cartouche vide et la remplacer par la recharge (comme illustré).
3. Refermer le couvercle.

Pour les meilleurs résultats:

- Procéder par mouvements lents et uniformes avec la tête pivotante à plat sur la surface du papier.

Ideal para cuadernos de fotos y láminas, creación de tarjetas y otros trabajos manuales con papel.

Para recargar:

1. Perfore las dos orejetas en el frente del aplicador y ábralo.
2. Levante y extraiga el cartucho usado y reemplácelo con uno nuevo (como se muestra en la figura).
3. Cierre bien la tapa.

Para obtener los mejores resultados:

- Deslice la punta del dispensador con un movimiento uniforme y lento, bien apoyada sobre la superficie del papel.