



decofoil™

iCraft® Deco Foil™ PeelnStick Toner Sheets - #3376

iCraft® Deco Foil™ PeelnStick Toner Sheets are heat-activated, adhesive-backed transfer papers used to create custom designs and embellishments. Use with Deco Foil™ Transfer Sheets to quickly and easily add a foil finish to your project!

Directions: For best results, always pre-test and gently wipe toner sheet with a lint-free cloth.

Directions are based on Royal Sovereign model # CS923/1223. Other brands/models, temperature and speed settings may vary.

1. Create a design using a punch, die cut, or an electronic cutter from the PeelnStick Toner Sheet.
2. Cut a piece of foil slightly larger than the design. Place foil, color side facing up, on top of the design. Place inside the folded parchment paper (included).
3. Turn on laminator, select 5mil setting, and allow 10 minutes to warm up. When ready, insert folded parchment with project into laminator using the crease as the lead edge.
4. Remove project from parchment paper. Peel foil transfer sheet away from design.
5. Remove liner to expose adhesive and place on project.

iCraft® Deco Foil™ DespegaryAdherir Hojas de Tóner se activa con el calor, adhesivo respaldado, papeles de transferencia utiliza para crear diseños y adornos personalizados. ¡Útilice con Deco Foil™ Hojas de Transferencia para agregar rápidamente un acabado metalizado a tu proyecto!

Instrucciones: Para obtener mejores resultados, siempre antes de la prueba y frote suavemente la hoja de tóner con un paño que no suelte pelusa.

Las instrucciones están basadas en el modelo # CS923/1223. Los ajustes de temperatura y velocidad para otras marcas o modelos pueden variar.

1. Cree un diseño usando un perforador, troquel o un cortador eléctrico a partir de DespegaryAdherir Hoja de Tóner.
2. Corte un pedazo de lámina ligeramente más grande que el diseño. Coloque la lámina, con el lado coloreado hacia arriba, sobre el diseño. Coloque dentro del papel de pergamino doblado.
3. Prenda la laminadora, seleccione la opción 5mil y deje que se caliente durante 10 minutos. Cuando esté lista, inserte el papel de pergamino doblado con el proyecto en la laminadora usando el pliegue como borde delantero.
4. Retire el proyecto del papel de pergamino. Despegue la lámina de transferencia del diseño.
5. Retire forro para exponer el adhesivo y colocarlo en el proyecto.