

SPRAYnBOND BASTING ADHESIVE - #4010

DIRECTIONS:

1. Pre-wash all materials without fabric softeners. Always pre-test on materials before starting project. Protect your work surface.
2. Shake well before use. Always spray back of item to be bonded.
3. Hold can upright, 12 inches from surface. Press nozzle and apply adhesive using a sweeping motion to lightly cover surface.
4. Press sprayed item onto project while still tacky. Reposition as needed.
5. Sew per project directions.
6. Hold can upside down and press for a short burst to clear nozzle before storing.
7. Cleans up with soap and water. Washes out in washing machine.



Spray



Press



Sew

TIPS:

- **Applique:** Spray back of appliqué to position on project before sewing.
- **Embroidery:** Spray on hooped stabilizer to hold fabric in place while embroidering.
- **Quilting:** Spray back of stencils, templates and quilt blocks to position on project while designing. Spray on fabric layers or batting to baste together without pinning!
- **Sewing:** Spray on tissue patterns to hold them onto fabric while cutting and piecing.