


## STICKY STRIP RUNNER™ - #3673

clear, double-sided adhesive strips  
bandes adhésives double face transparentes  
tiras adhesivas transparentes de dos lados

Great for scrapbook paper & photos, card making and other paper crafts.



### General Directions:

1. Grasp applicator with index finger on top and press against paper at a 45° angle.  
( as shown )
2. Slowly pull runner across surface.

### For Best Results:

- Use slow, consistent movement with head flat on paper's surface.

Parfait pour le papier et les photos dans les albums de souvenirs, la fabrication de cartes et autres projets.

### Mode d'emploi:

1. Saisir l'applicateur avec l'index sur le dessus et presser contre le papier à 45° (comme illustré).
2. Tirer lentement à travers la surface.

### Pour les meilleurs résultats:

- Procéder par mouvements lents et uniformes avec la tête à plat sur la surface du papier.

Ideal para cuadernos de fotos y láminas, creación de tarjetas y otros trabajos manuales con papel.

### Instrucciones generales:

1. Sujete el aplicador con el dedo índice colocado sobre él y presione contra el papel en un ángulo de 45° (como se muestra en la figura).
2. Deslice lentamente el dispensador por la superficie.

### Para obtener los mejores resultados:

- Deslice la punta del dispensador con un movimiento uniforme y lento, bien apoyada sobre la superficie del papel.